

# Secure Digital Still Camera & Digital Video Camera Compatibility List

AIPTEK DB-5300  
Axia Eyeplate EPMEGA  
BenQ C40  
BenQ C50  
BenQ DC 2410  
BenQ DC 4330  
BenQ DC C30  
BenQ DC C51  
BenQ DC E30  
BenQ DC E40  
BenQ DC E43  
BenQ DC S30  
BenQ DC1500  
BenQ DC2310  
BenQ DC2410  
BenQ DC3400  
BenQ DC3410  
BenQ DC50  
BenQ DC5330  
BenQ DC-S30  
BenQ DigiArt250  
BenQDC 2410  
Besta DC-521  
Besta Digi-eye S2  
Canon 1D Mark 2 FAT32  
Canon 40-MC  
Canon ELURA50  
Canon FV M1  
Canon FV10  
Canon FV40  
Canon FV50 KIT  
Canon FVM1  
Canon FVM100  
Canon GL2A  
Canon IXUS I  
Canon IXUS II  
Canon IXY  
Canon IXY Digital  
Canon IXY Digital 30  
Canon IXY Digital 30a  
Canon IXY Digital 50  
Canon IXY DV M  
Canon IXY DV3  
Canon IXY L2  
Canon IXY M2  
Canon IXY30a  
Canon IXYDV M3  
Canon Optura20  
Canon Optura200MC  
Canon Pixus MP370

Canon PowerShot A400  
Canon PV130  
Canon SD10 FAT32  
Canon SD100 FAT32  
Canon SD110 FAT32  
Canon XV2  
Canon ZR45MC  
Canon ZR-70-MC  
Canon ZR85  
CASIO Exilim EX-M2  
CASIO Exilim EX-S1  
CASIO Exilim EX-S2  
CASIO Exilim EX-S20  
CASIO Exilim EX-S20U FAT32  
CASIO Exilim EX-S3  
CASIO Exilim EX-Z3  
CASIO Exilim EX-Z4  
CASIO Exilim EX-Z4U FAT32  
CASIO EX-M20  
CASIO EXP600  
CASIO EX-S100  
CASIO EX-Z30  
CASIO EX-Z4  
CASIO EX-Z40  
CASIO EX-Z50  
CASIO EX-Z55  
CASIO QV-2100  
CASIO QV-R3  
CASIO QV-R4  
CASIO QV-R40  
CASIO QV-R41  
CASIO QV-R51  
CASIO QV-R61  
Concord 4360-Z  
Contax LV  
Contax SL300R  
Contax T-VS  
CREATIVE PC-CAM-880  
Digilife DDV-S670  
Digilife DG-L660  
Digilife DG-M6  
Digilife DG-Q4  
Digilife DG-V4  
Digilife DV-A4  
Digimaster 210 Mouse  
Digimaster Can walk DG-2000  
Digimaster DIAMOND 660  
Digimaster I-gic  
Digimaster i-gic Super (4.0 mega)  
Digimaster I-gic4 (4.0 mega)  
Digimaster M3  
Digimaster Mouse 410  
Digimaster POW300  
Digimaster POWER300  
Digimaster Q-Shot (5.0 mega)  
Digimaster S500

Digimaster Sex1 (4.0) Zoom Lens  
Digimaster Skipper  
Digimaster V6R  
DXG DVC305  
EasyShare 6490  
EPSON L-300  
EPSON L-400  
EPSON L-410  
EPSON L-500V  
FASHION CAM DSC-321  
FASHION CAM FASHION CAM  
FASHION DXG660  
FASHION FASHION CAM 4-IN-1  
FISHER FVD-C1  
Fujitsu Siemens Options2  
FunTwist D-Clip 200  
FunTwist D-Clip 300  
FunTwist D-Clip 310  
GATEWAY DC-M42  
GATEWAY DC-T20  
GATEWAY DC-T50  
GATEWAY DV-S20  
Genius D211  
Hitachi DZ-MV380A  
Hitachi Living Systems HDC-2V  
Hitachi Living Systems HDC-301SLIM  
Hitachi Living Systems HDC-401  
HP 320  
HP 635  
HP PhotoSmart 435 FAT32  
HP PhotoSmart 620  
HP PhotoSmart 720  
HP PhotoSmart 812  
HP PhotoSmart 850  
HP PhotoSmart 935  
HP PhotoSmart 945  
HP PhotoSmart M305  
HP PhotoSmart M307  
HP PhotoSmart M407  
HP R607  
HP R707  
I-O DATA AVMC211  
I-O DATA AVMC212  
Jenoptik JD C1.3  
JVC D70K  
JVC DVP9  
JVC GD-D231U  
JVC GR-D230  
JVC GR-D230U  
JVC GR-D90U  
JVC GR-D93U  
JVC GR-DV3000  
JVC GR-DV800U  
JVC GR-DV900  
JVC GR-DV900U

JVC GR-DVL520  
JVC GR-DVL820U  
JVC GR-DVM90  
JVC GR-DVM96U  
JVC GR-DVP3E  
JVC GR-DVP7  
JVC GR-DVX600K  
JVC GR-DX307  
JVC GR-DX307U  
JVC GR-DX95K  
JVC GR-DX95U  
JVC GR-DZ7  
JVC GR-DZ7U  
JVC GZ-MC100  
JVC GZ-MC200  
JVC GZ-MC200U  
JVC Mini D Camera Model 820  
JVC PV-GS12  
JVC ZR90  
Kodak CX-4200  
Kodak CX-4230  
Kodak CX-4300  
Kodak CX-6200  
Kodak CX-6230 FAT32  
Kodak CX-6330 FAT32  
Kodak CX-7300  
Kodak CX-7330  
Kodak CX-7430  
Kodak CX-7530  
Kodak DCS Pro SLRn  
Kodak DX-3215  
Kodak DX-3700  
Kodak DX410Z  
Kodak DX-4330 FAT32  
Kodak DX-4530 FAT32  
Kodak DX500Z  
Kodak DX510Z  
Kodak DX-6340 FAT32  
Kodak DX-6440 FAT32  
Kodak DX-6490 FAT32  
Kodak DX-7440  
Kodak DX-7630  
Kodak EasyShare LS743  
Kodak LS-420  
Kodak LS-430  
Kodak LS-443 FAT32  
Kodak LS-630  
Kodak LS-633  
Kodak LS-6940  
Kodak LS-743  
Kodak LS-753  
Kodak Pro back 14N  
Kodak VQ3240  
Kodak VQ3350  
Kodak VQ3350  
Konica Minolta DG-4W

Konica Minolta DiMAGE 7V2  
Konica Minolta DiMAGE E223  
Konica Minolta DiMAGE E323  
Konica Minolta DiMAGE F100  
Konica Minolta DiMAGE F200  
Konica Minolta DiMAGE F300  
Konica Minolta DiMAGE G400  
Konica Minolta DiMAGE G500  
Konica Minolta DiMAGE G530  
Konica Minolta DiMAGE G600  
Konica Minolta DiMAGE X  
Konica Minolta DiMAGE X20  
Konica Minolta DiMAGE X31  
Konica Minolta DiMAGE X50  
Konica Minolta DiMAGE XG  
Konica Minolta DiMAGE Xg1  
Konica Minolta DiMAGE Xi  
Konica Minolta DiMAGE XT  
Konica Minolta DiMAGE Z1  
Konica Minolta DiMAGE Z10  
Konica Minolta DiMAGE Z2  
Konica Minolta DiMAGE Z20  
Konica Minolta DiMAGE Z3  
Konica Minolta DiMAGE Z5  
Konica Minolta KD-100Z  
Konica Minolta KD-200Z  
Konica Minolta KD-220Z  
Konica Minolta KD-300Z  
Konica Minolta KD-310Z  
Konica Minolta KD-3300Z  
Konica Minolta KD-400Z  
Konica Minolta KD-420Z  
Konica Minolta KD-500Z  
Kyocera Contax SL300RT  
Kyocera Contax Tvs  
Kyocera Finecam L3  
Kyocera Finecam L30  
Kyocera Finecam L3V FAT32  
Kyocera Finecam L4  
Kyocera Finecam L4V  
Kyocera Finecam M400  
Kyocera Finecam M400R  
Kyocera Finecam M410R  
Kyocera Finecam S3  
Kyocera Finecam S3L FAT32  
Kyocera Finecam S3R  
Kyocera Finecam S3X  
Kyocera Finecam S4 FAT32  
Kyocera Finecam S5 FAT32  
Kyocera Finecam S5R  
Kyocera Finecam SL300R  
Kyocera Finecam SL400R  
Leica Digilux-1  
Maginon DC3300  
MEGXON C330  
MEGXON C430

Microtek Take-it MV300  
Microtek Take-it S3  
MILEI DigiArt660  
Minton Chipset: Sunplus 533  
Mustek DV3000  
Mustek DV3500  
Mustek DV4000  
Mustek DV6M  
Mustek GSMART G35  
Mustek MDC 5000  
Mustek MDC 5500Z  
NHJ CheEZ H2O  
NHJ DZ320  
NHJ DZ438  
NHJ D'zign DV-4  
NHJ FOXZ2  
NHJ Mach-Power DX-450  
Nikon Coolpix 2200  
Nikon Coolpix 3200  
Nikon Coolpix 3700  
Nikon Coolpix 4100  
Nikon Coolpix 4200  
Nikon Coolpix 4600  
Nikon Coolpix 4800  
Nikon Coolpix 5200  
Nikon Coolpix 5600  
Nikon Coolpix 5900  
Nikon Coolpix 7900  
Nikon Coolpix S1  
Orite DC3110  
Panasonic DMC-F1  
Panasonic DMC-F1K  
Panasonic DMC-F7  
Panasonic DMC-FX1  
Panasonic DMC-FX2  
Panasonic DMC-FX5  
Panasonic DMC-FX7  
Panasonic DMC-FZ1  
Panasonic DMC-FZ10  
Panasonic DMC-FZ2  
Panasonic DMC-FZ20  
Panasonic DMC-FZ3  
Panasonic DMC-LC1  
Panasonic DMC-LC20  
Panasonic DMC-LC3  
Panasonic DMC-LC43  
Panasonic DMC-LC5  
Panasonic DMC-LC50  
Panasonic DMC-LC70  
Panasonic GS50K  
Panasonic MX500  
Panasonic NV-100K  
Panasonic NV-50K  
Panasonic NV-70K  
Panasonic NV-C7  
Panasonic NV-DS38

Panasonic NV-DS65  
Panasonic NV-DS88K  
Panasonic NV-EX21  
Panasonic NV-GS100K  
Panasonic NV-GS120K  
Panasonic NV-GS200K  
Panasonic NV-GS400K  
Panasonic NV-GS50K  
Panasonic NV-GS55K  
Panasonic NV-GS5K  
Panasonic NV-GS70  
Panasonic NV-GS70K  
Panasonic NV-GX7K  
Panasonic NV-MX1000  
Panasonic NV-MX5000  
Panasonic NV-MX7DEN  
Panasonic optura 100MC  
Panasonic PD-DV852D  
Panasonic PV-DC3000  
Panasonic PV-DC3000J-G  
Panasonic PV-DC3010  
Panasonic PV-DL352  
Panasonic PV-DV103  
Panasonic PV-DV202  
Panasonic PV-DV203  
Panasonic PV-DV2520  
Panasonic PV-DV402  
Panasonic PV-DV952  
Panasonic PV-DV953  
Panasonic PV-GS15  
Panasonic PV-GS55  
Panasonic PV-GS70  
Panasonic PV-VM102  
Panasonic PV-VM202  
Panasonic SV-AS10--MP3  
Panasonic SV-AU10U  
Panasonic SV-AV10  
Panasonic SV-AV100  
Panasonic SV-AV30  
Panasonic SV-AV50  
Panasonic SV-SD50  
Panasonic VDR-M30K  
Panasonic VDR-M70K  
Pentax Optio 33LF  
Pentax Optio 33WR  
Pentax Optio 40  
Pentax Optio 43WR  
Pentax Optio 550  
Pentax Optio 555  
Pentax Optio 750Z  
Pentax Optio S  
Pentax Optio S30  
Pentax Optio S4  
Pentax Optio S40  
Pentax Optio S4i  
Pentax Optio S50

Pentax Optio S5i  
Pentax Optio SV  
Pentax Optio X  
Polaroid iON230  
Polaroid PDC 3070  
Praktica DV3  
Premier DC2070  
Premier DC2302  
Premier DC3000  
Premier DC3001  
Premier DC3301  
Premier DC3305  
Premier DC3306  
Premier DC4311  
Premier DC5300  
Premier DC5330  
Premier DC5566  
Premier DS-210  
Premier DS4330  
Premier DV-2000  
Premier F4  
Premier Max-101  
Premier S2303  
Premier S320  
Premier X5  
Pretec DV3300D  
Pretec DV4200i  
Primax Ezonic Discovery  
Primax Ezonic EZ-S220  
Primax Yoson  
Ricoh Caplio 300G  
Ricoh Caplio 400G Wide  
Ricoh Caplio G2  
Ricoh Caplio G3  
Ricoh Caplio G4  
Ricoh Caplio G4 wide  
Ricoh Caplio GX  
Ricoh Caplio RR30  
Ricoh Caplio RX  
Ricoh G4 Wide  
Ricoh R300G  
Ricoh RR 1  
Ricoh RR-10  
RITE VC-3300  
RWC MobiDV-H10  
Samsung D370  
Samsung D4000  
Samsung D401  
Samsung Digimax 430  
Samsung DigiMax-101  
Samsung DigiMax-201  
Samsung DigiMax-240  
Samsung DigiMax-V3  
Samsung DigiMax-V4  
Samsung DigiMaX-V5  
Samsung DigiMax-V50

Samsung Digital CAM VMD797E (4  
bit  
Samsung SC-D107  
Samsung SC-D307  
Samsung U-CA5  
Samsung V4000  
Sanyo Dmx-C1  
Sanyo DMX-C4  
Sanyo DSC-J1  
Sanyo VPC-J1EX  
Sanyo VPC-J2  
Sanyo Xacti J4  
Sanyo Xacti S1  
Sanyo Xacti S3  
Sanyo Xacti S4  
Sharp VL-MG10  
Sharp VL-NZ10  
Sharp VL-Z5  
Sharp VL-Z7  
Sharp VL-Z75  
Sharp VL-Z7U  
Sharp VL-Z900  
SIPIX CAM DV100  
Syntek Semiconductor STK1200  
TCL TDC1818  
Tekxon AX-480  
Tekxon CX-432  
Tekxon SX400  
Tekxon TX 3000  
Tekxon TX 5000  
Tekxon TX 5500  
Tekxon TX MVP  
Tekxon TX-1  
Tekxon TX-2 (upto 256MB)  
Toshiba PDR M700  
Toshiba PDR T-10  
Toshiba PDR T-15  
Toshiba PDR T-20 FAT32  
Toshiba PDR2300  
Toshiba PDR3300  
Toshiba PDR-3310 FAT32  
Toshiba PDR-4300  
Toshiba PDR-5300  
Toshiba PDR-M500  
Toshiba PDR-M700  
Toshiba PDR-T15(KT)  
Toshiba PDR-T20S  
Toshiba PDR-T30  
Toshiba Pro Tege 2000  
Toshiba Pro Tege 3500  
Traveler DC-4300  
UMAX Power Cam 3660  
Veo Smart Cam 2.1  
VICTOR GR-DVP7  
VICTOR GR-DVX600K  
VICTOR GR-DX307

VICTOR GR-DX95K  
Vivitar ViviCAM3330 FAT32  
Vivitar ViviCAM3625 FAT32  
Vivitar ViviCAM3765  
Vivitar ViviCAM3825  
Vivitar ViviCAM3935  
VMAX Astra Pix610  
VPC J2  
WOLVERINE DC 400  
Yakumo CX200